


























# PIANO GRANDE Kookupanekujuhend • Assembling instruction

PG212S



- 1 Põhi • Bottom - 1 tk/unit
- 2 Külgsein • Side - 1 + 1 tk/unit
- 3 Vahesein • Middle panel - 1 tk/unit
- 4 Tagasein • Back - 2 tk/unit
- 5 Riil • Shelf - 2 tk/unit
- 6 Lagi • Top - 1 tk/unit
- 7 Uks • Door - 1 tk/unit
- 8 Uks • Door - 1 tk/unit

 <b>A</b> 8x24	 <b>K2</b> Ø4x16
 <b>B</b> Ø15x13,2	 <b>K3</b> Ø3x15
 <b>C</b> Ø15	 <b>R</b> 4x
 <b>D</b> 5x	 <b>S</b> 4x
 <b>E</b> Ø5	 <b>O</b> 4x
 <b>F</b> Ø6x35	 <b>P</b> M4x23
 <b>G</b> Ø8x35	 <b>T</b> 1x
 <b>H</b> Ø6x60	 <b>U1</b> 2x
 <b>KP</b> 2x	 <b>Q</b> 2x
 <b>Y</b> 2x	 <b>K5</b> Ø3x20



 **Standard**

