






















PIANO GRANDE Kookupanekujuhend • Assembling instruction

PG208S

Standard



- 1 Põhi • Bottom - 1 tk/unit
- 2 Külgesein • Side - 1 + 1 tk/unit
- 3 Vahesein • Middle panel - 1 tk/unit
- 4 Tagasein • Back - 2 tk/unit
- 5 Riiul • Shelf - 2 tk/unit
- 6 Lagi • Top - 1 tk/unit
- 7 Uks • Door - 1 tk/unit
- 8 Uks • Door - 1 tk/unit

 A 8x24	 K2 Ø4x16
 B Ø15x13,2	 K3 Ø3x15
 C Ø15	 R 4x
 D 5x	 S 4x
 E Ø5	 O 4x
 F Ø6x35	 P M4x24
 G Ø8x35	 T 1x
 H Ø6x60	 U1 2x
 KP 2x	 Q 2x
 Y 2x	 K5 Ø3x20

