




STANDARD

## PIANO, SERIE


TEKSTIILIGA KAETUD PANEELIDE montaazijuhend • Assembling instruction of TEXTILE COVERED PANELS

PAP0804K, PAP0807K, PAP0704K, SEP0812K, SEP0612K, SEP0912K, SEP0604K,  
SEP0608K, SEP0816K, SEP0808K, SEP0804K


- 1.** eemalda pool teibist paneeli küljest •  
remove one half of the tape from the panel



**NB!**



- 2.** eemalda teibilt kattepaber ja suru teip tugevalt riuli/kapi tagaseina külge •  
peel of the paper backing from the tape and press strongly to the back wall of the shelf/cabinet



- 3.** palun oota 15 minutit, liim kuivab •  
please wait 15 minutes until the glue is dry

- 4.** aseta paneel tausta suhtes sirgelt •  
press the panel to back wall of the cabinet while holding it straight

