


# SOFT

## Kokkupanekujuhend • Assembling instruction

	<b>SOVS080120</b> H1240x800x40 <b>SOVS100120</b> H1240x1000x40 <b>SOVS120120</b> H1240x1200x40 <b>SOVS140120</b> H1240x1400x40 <b>SOVS160120</b> H1240x1600x40	<b>SOVS080160</b> H1640x800x40 <b>SOVS100160</b> H1640x1000x40 <b>SOVS120160</b> H1640x1200x40 <b>SOVS140160</b> H1640x1400x40 <b>SOVS160160</b> H1640x1600x40	 <b>SOLSR</b> <b>A x4</b>
	<b>SOVS080140</b> H1440x800x40 <b>SOVS100140</b> H1440x1000x40 <b>SOVS120140</b> H1440x1200x40 <b>SOVS140140</b> H1440x1400x40 <b>SOVS160140</b> H1440x1600x40	<b>SOVS080180</b> H1840x800x40 <b>SOVS100180</b> H1840x1000x40 <b>SOVS120180</b> H1840x1200x40 <b>SOVS140180</b> H1840x1400x40 <b>SOVS160180</b> H1840x1600x40	 <b>M6x20</b> <b>B x4</b>  <b>M6</b> <b>C x4</b>



**NB! KONTROLLI, ET RATTAD KINNITUKS  
JALGADE KÜLGE**

**CHECK THAT THE CASTORS ARE  
FITTED TIGHTLY**