


PIANO GRANDE




















Kokkupanekujuhend • Assembling instruction

PG206S

Standard



- 1 Põhi • Bottom - 1 tk/unit
 2 Külgsein • Side - 2 tk/unit
 3 Uks • Door - 1+1 tk/unit
 4 Tagasein • Back - 1 tk/unit
 5 Riil • Shelf - 1 tk/unit
 6 Lagi • Top - 1 tk/unit

 F 8x	 G 16x
 D1 2x	 D 4x
 R 1x +  L 1x +  K3 2x	 U 1x +  K2 2x
 V 1x +  K2 2x	 A +  B +  C 12x 8x24 12x Ø15x13,2 12x Ø15 12x
 N +  M +  K1 4x 4x 8x	 KP +  P 2x M4x23 4x

