








PIANO Kokkupanekujuhend • Assembling instruction






















PAK3








- 1 Lagi • Top - 1 tk/unit
- 2 Külgsein • Side - 2 tk/unit
- 3 Vahesein • Middle panel - 1 tk/unit
- 4 Tagasein • Back - 2 tk/unit

 A 8x24 6x	 F Ø6x35 4x
 B Ø15x13,2 6x	 G Ø8x35 6x
 C Ø15 6x	 H Ø6x60 2x

- 1 Põhi • Bottom - 1 tk/unit
- 2 Külgsein • Side - 1 + 1 tk/unit
- 3 Vahesein • Middle panel - 1 tk/unit
- 4 Tagasein • Back - 2 tk/unit
- 5 Riiul • Shelf - 2 tk/unit
- 6 Lagi • Top - 1 tk/unit
- 7 Uks • Door - 1 tk/unit
- 8 Uks • Door - 1 tk/unit

 A 8x24 18x	 K2 Ø4x16 8x
 B Ø15x13,2 18x	 K3 Ø3x15 2x
 C Ø15 18x	 R 4x
 D 6x	 S 4x
 E Ø5 8x	 O 4x
 F Ø6x35 8x	 P M4x24 4x
 G Ø8x35 18x	 T 1x
 H Ø6x60 4x	 U1 2x
 KP 2x	 Q 2x
 Y 2x	 K5 Ø3x20 2x
 J 6x	



PIANO Kookupanekujuhend • Assembling instruction

PAK3

Standard

