







SERIE Kokkupanekujuhend • Assembling instruction





SE4331P SE4331S SE4331M SE4331R




 8x24 A 12x	 ø15x13.2 B 12x
 ø15 C 8x	 D 4x
 ø8x35 F 20x	 ø5 E 4x









- 1 Põhi ▪ Bottom - 1 tk/unit
- 2 Külgsein ▪ Side - 2 tk/unit
- 3 Vahelagi ▪ Middle top - 1 tk/unit
- 4 Tagasein ▪ Back - 1 tk/unit
- 5 Riul ▪ Shelf - 1 tk/unit
- 6 Lagi ▪ Top - 1 tk/unit






SERIE Kokkupanekujuhend • Assembling instruction



 H 1x	 H1 2x φ3.5x15	 K 2x
 J 1x M5x10	 P 4x M4x23	
 L 4x	 M 4x	
 N 16x φ3.5x12		



A - uksed / doors
B - käepidemed / handles



7 Uks parem ▪ Door right - 1 tk/unit
8 Uks vasak ▪ Door left - 1 tk/unit

Ukse kõrguse reguleerimine
Door height adjustment

S.
STANDARD