Assembly Instructions

Parts and Tools list

NO.	Name	Qty	NO.	Name	Qty
1	Legs	4	12	M6*20 Screw	8
2	Brackets	4	13	ST4.8*19 Screw	24
3	Beam	2	14	ST3.5*19 Screw	4
4	Cable Tray	1	15	M6*12 Screw	16
5	Screen Stand	4	16	Rubber Cushion	20
6	Connection Beam	2	17	M6*16 Screw	8
7	4mm Hex Spanner	2			
8	5mm Hex Spanner	2			
9	M8*10 Screw	8			
10	Gasket8	8			
11	M6*14 Screw	16			

1 Loosen the 8 screws of beam using 4MM hex spanner, adjust the beam to proper position to fit the desktop we recommend leaving 15CM of the desktop width (on each end) and then tighten screws

2 Attach legs to the beam using 8 of M6*14 screws and 4 of M6*12 screws, the other side is same

4mm Hex Spanner

M6*12 Screw 8PCS

M6*14 Screw 8PCS

3 Attach connection beam to leg using 8 of M8*10 screws and 8 of gasket8.

5mm Hex Spanner

M8*10 Screw 8PCS

Gasket8 8PCS

4 Open the cover of cable tray,using 4rm Hex spanner to loosen the screws on both sides of cable tray,and then adjust the cable tray’s length.

Assembly Instructions

5 Overturn frame, and fixed the cable tray, then attach screen stand to connecting beam using 5mm Hex Spanner and 8 of M6*20 screws and close the lid of cable tray.

6 Attach connection brackets to beam using 8 of M6*12 screws and then fit the rubber cushions to the brackets and beams.

7 Fix table top to frames with 12 of ST4.8 screws, then fix control boxes to below table top with 4 of ST4.8 screws, at last fix handsets to below table top with 4 of ST3.5 screws (you can use the self tapping screw or in case of inserts use the M6*16 screw).

8 Connect the control box to the handset and to the motor